

# Tovcol LVT Fibre+

## Fibre-reinforced acrylic adhesive for LVT

Solvent-free, acrylic fibre-reinforced adhesive for the bonding of LVT/SPC flooring and wall coverings on absorbent substrates. Fast and strong initial tack, excellent adhesion, and outstanding dimensional stability. Also suitable for use on heated substrates. Can be used in areas exposed to high temperatures. For interior use only.

### Technical data at 20 °C, 60% R.H.

Appearance	Beige paste
Density	1,29 kg/litre
Waiting time	0–10 minutes for flooring 5–10 minutes for wall coverings
Open time	15 – 20 minutes
Light traffic	5 – 6 hours
Complete curing	3 days
Yield	250 – 300 g/m <sup>2</sup> - TKB/A2 spatula
Application temperature	Min +15 °C, max +35 °C
Temperature of use (adhesive completely hardened)	From - 20 to + 50 °C
Shelf-life	12 months Protect from freeze
Tools cleaning	With water till the product is fresh, with Solvente S 23 if dry
Packing	5 and 12 kg pails

### Sub-floor preparation

Tovcol LVT Fibre+ can be applied on any absorbent sub-floor in good conditions i.e. even, strong, clean, without grease or other residues. The maximum acceptable humidity level is < 2,0% (1,7 % in case of under heating). On gypsum or anhydrite sub-floors the humidity must be less than 0,5% (0,2% in case of under heating). On dusty sub-floors apply a coat of Nano-Fix water-based primer. In case of non-absorbent supports, apply at least 2 mm of self-levelling compound. Under heating must be prepared according to the supplier instructions. Switch off heating 24 hours before laying.

### Application

Acclimate both the adhesive and the flooring at least 24 hours before laying. Accurately mix the adhesive before using it. Apply Tovcol LVT Fibre+ with a suitable notched trowel (TBK A2), lay the LVT tiles or stripes within the adhesive open time. Periodically check the good transfer of the adhesive on the LVT back. If the open time is over and the transfer is not enough, remove the adhesive and repeat the application. Roll up the flooring with a 60 kg roller from the centre to the edges of the room in order to avoid air bubbles. Repeat the operation after 20 – 30 minutes. Immediately clean adhesive residues or spots with a wet cloth.

For wall applications, observe a waiting time of 5–10 minutes before proceeding with bonding. Follow the flooring supplier instructions too.



ADHESIVES  
& SEALANTS



### CERTIFICATIONS



## Notes

- Both open time and waiting time may vary according to temperature and humidity conditions inside the room.
- Do not use for floorings subject to constant water.
- Protect from freeze. Store at temperature superior to +5 °C.

## Safety rules

For professional use only. Strictly respect the information reported on the labels and consult the safety data sheet before using the product.

## Waste disposal

Dispose not used products and empty containers in accordance to local in force regulations.



**ADHESIVES  
& SEALANTS**



## CERTIFICATIONS



The information reported in present technical data sheet are for guidance only and they do not hold our responsibility. Adapt the use of our products to the environmental conditions and materials to be treated.

Rev 05– 29/01/2026. Current Technical Data Sheet replaces the previous one.