

Sportfloor Grip&Play

Anti-slip agent for sports floors



Cleaning & Maintenance

Sportfloor Grip&Play improves the non-slip properties of the surface. It is indicated for the preparation of the playing field before a game and to improve the grip of the players' shoes.

Technical data at 20 °C – 60% R.H.

Appearance	Transparent liquid
Density	1,00 kg/litre
pH	8,0
Storage	24 months in sealed original package – Frost sensitive
Packaging	1 litre bottles, 5 litre tanks

How to use

To prepare the playing court – Wash the floor with Sportfloor Cleaner or, in case of more intense dirt, Sportfloor Cleaner N2. Pour two caps of Sportfloor Grip&Play into 5 litres of water and apply over the entire surface using a well-wrung damp cloth. It is not necessary to rinse. Avoid excess or stagnation of product on the floor as it could lead to an increase in slipperiness.

To prepare the players' shoes – Pour pure Sportfloor Grip&Play onto a damp towel and rub the soles of players' shoes periodically during the game.

Dirty Sportfloor Grip&Play cloths can be washed by rinsing them with clean water.

Notes

- Shake before use.
- Do not exceed the recommended ratio for dilution and do not exceed the quantity of product applied.

Safety regulations

Product for professional use: Strictly comply with what is stated on the label and consult the safety data sheet before using the product.

Disposal

Dispose of the unused product and empty packaging in accordance with the local legislation in force.

Sportfloor Grip&Play



The recommendations in this technical data sheet are given for information only and do not bind our responsibility in any way since the methods and conditions of use of the product are beyond our control. We recommend checking the actual suitability for the intended use.

Rev 04 – 05/07/2023. – This technical data sheet cancels and replaces the previous one.